

Troubleshooting Spot Sprayer Pumps	
Pump Will Not Run	Check for loose wiring
	Confirm the on/off switch is on
	Check Fuses (pump and wire set)
	Check Pressure Switch
	Check for Clogged strainer
Low Pressure/Low Flow	Check for Proper Voltage
	Try another power source
	Check Fluid level in tank
	Check for Clogged strainer
Pump Surges	Check Fluid level in tank
	Check for Clogged strainer
	Low Flow not enough Demand
	Slightly open Bypass (if applicable) to overcome issue
	Adjust Pressure Switch (Quarter turn clockwise until surge stops)
Pump continues to run	Bypass not closed
	System has leaks
	No liquid in tank
Blown Fuse	Excessive Voltage
	Pressure Switch needs adjustment or replaced
	Wiring Harness Damaged or defective