

FITTING GUIDE

SUPERRIP AGGRESSIVE POINT

COMPATIBLE WITH CASEIH MACHINES

THE LEADER IN LONGEVITY

AGRITUF points go the distance. Ensure proper fitting for the best results.



STEP ONE

Double check you have the AGRITUF bolt for the SuperRip Aggressive Point (this comes with the point).



STEP FOUR

Place a washer on each end of the bolt and fasten with a lock nut, retaining the ripper point onto the shank. The nut should reach the end of the thread and be tightened securely.



STEP TWO

Slide the ripper point onto the shank, lining up the bolt holes.



STEP FIVE

Place the shank protector on the shank, lining up the top and bottom bolt holes.



STEP THREE

Fit the bolt through the lined up holes of the point and shank.



STEP SIX

Install a roll pin through each of the two holes, securing the shank protector onto the shank.

MAKE AGRITUF DO THE HARD YARDS

BOLT THREE POINTS ONTO YOUR MACHINE, AND PUT THEM IN HIGH WEAR AREAS - THEN YOU'LL SEE WHY THEY ARE THE BEST.

- 1 Point one in the centre
- 2 Point two behind the wheel
- 3 Point three outside edge





SUPERRIP AGGRESSIVE POINT PRODUCT CARE GUIDE

GENERAL CARE

Our superior performance is thanks to our unique chromium blend. To keep AGRITUF points performing at their peak, keep these in mind.

DON'T DROP THEM

Avoid dropping AGRITUF points on hard surfaces our points have been designed for point first soil penetrations.

CARE WHEN LOWERING

Pay attention when lowering the machine on uneven surfaces where weight distribution onto a point(s) might cause damage.

DON'T OVER TIGHTEN

Caution when tightening with a impact gun. Do not over tighten.

MAINTAIN EQUIPMENT

While AGRITUF points go further than our competitors, they do still wear. To get the best results, make sure you're regularly checking and maintaining equipment.

EVEN TORQUE

Torque up bolts evenly with double bolt hole castings.

AGRITUF.COM

f FACEBOOK.COM/AGRITUF



INSTAGRAM.COM/AGRITUF